PIONEER CLOTHING

INSTRUCTIONS FOR SEWING

Stitching Hearts World Wide

- **RST** = right sides together
- **WST** = wrong sides together

Use a sharp needle, a 2.0 stitch length, matching thread, and 1/4" **seam** unless otherwise indicated

SKIRT

Stitch **skirt front to back** at side seams with %" seam. Optional - zigzag edges and press open.

Press top edge under ¼".

Press under another 1¼" to form casing for elastic.

Cut elastic to your waist measurement plus ½".

Overlap ends ½" and stitch into a loop.

Place elastic inside fold. Stitch 1/8" from edge, gathering skirt onto elastic.

Press bottom edge under in a double-rolled ¼" hem. Stitch.



APRON

Attach a safety pin 1" below point of each **apron tie.** Fold **RST**, with safety pin inside.

Starting at the point, sew down the long edge, stopping 2" before end. Turn right side out and press.

Press **apron waistband** in half WST. Press one long edge under 1/4".

Sew short ends **apron waistband** to an **apron tie** to form one long strip.



Press **apron** sides and bottom under in a double-rolled $\frac{1}{4}$ " hem (press under $\frac{1}{4}$ " and then under another $\frac{1}{4}$ "). Stitch hem.

Lengthen stitch to 5 and, without backstitching, sew two gathering lines across top of apron at $\frac{1}{8}$ " and $\frac{1}{4}$ ", leaving thread tails on each end. Gather top edge of apron to 18".

Return stitch length to normal.

Pin WRONG side of gathered apron to RIGHT side of unpressed apron waistband edge and sew together.

Fold **apron waistband** to front. Pin in place to cover seam.



Topstitch 1/16" from point of one **apron tie**, across **apron waistband**, **and** to point of other tie.

Stitch 2 sets of **apron pockets** RST leaving a 1 1/2" opening in top edge for turning. Turn and press, folding raw edges of opening to inside.

Topstitch 1/8" from top edge of each apron pocket.

Try on the apron on and mark where the tips of your fingers reach. Then, measuring from the top, pin so the bottom of each **apron pocket** is **2**" above mark, and **4**" in from the side of the apron.

Stitch 1/8" from the edge of the pocket, down one side, across the bottom, and up the other side.

BONNET

Attach a safety pin 1" below point of each **bonnet tie.** Fold **RST** and stitch. Turn right side out and press. Trim off selvage.

Stitch curved side of **bonnet brims** RST.

Apply fusible interfacing, turn right side out and press. Draw a dot at center of unsewn edge.

Pin each **bonnet tie** with raw edge to each curved side of **bonnet brim** parallel to and 1/4" above unsewn edge.

Topstitch curved side of **bonnet brim** $\frac{1}{8}$ " from sewn edge, attaching ties. Stitch tie again $\frac{1}{8}$ " away.

Trim raw end of **bonnet ties** to match curves of **bonnet brim**. Fold tie back on itself and stitch in place.

On **bonnet**, press neck edges and bottom under in a double-rolled ½" hem. Stitch.

Draw a dot at center of curved edge of **bonnet**. *Lengthen stitch to 5* and sew two gathering lines across top edge of the bonnet at ½" and ½", leaving thread tails on each end - do not backstitch on either end. *Return stitch length to normal.*

Pin **bonnet** to **bonnet brim** RST at edges and center. Gather **bonnet** to fit **bonnet brim**. (More gathers near the center of the bonnet and fewer gathers near the edges make the bonnet puff up nicely on top.)

Stitch **bonnet** to **bonnet brim**. Go slowly and adjust fabric so gathers are even and perpendicular to **bonnet brim**. (If this makes you nervous, baste it first and then sew it.) Zigzag edges.

Mark center of elastic and center of **bonnet** on gathering line. Sandwich the ends off the elastic between **bonnet brim** seam and **bonnet** on both sides and stitch. With one tacked end under machine's presser foot, put needle down and stretch elastic to fit. Zigzag.

